


ORDER #05400



INSTALLATION INSTRUCTIONS:

- 1) SET CONCRETE BASE AS SHOWN (MINIMUM 24" DEEP CEMENT BASE: CONSULT LOCAL BUILDING DEP'T)
- 2) ASSEMBLE TOWER SEPARATELY: CONNECT LOWER PIPE & UPPER PIPE TO SHUTOFF VALVE, THEN ATTACH STREET ELBOW AND SLIDE THROUGH BODY PIPE. TIGHTEN HANDLE OF SHUTOFF VALVE TO VALVE BODY.
- 3) ATTACH INSIDE HOSE TO ARM PIPE AND SLIDE THRU HEAD SPRING ASSEMBLY, COILING INSIDE HOSE WITHIN HEAD SPRING ASSEMBLY.
- 4) CONNECT INSIDE HOSE WITH BUSHING TO UPPER PIPE, AND THEN MOUNT HEAD SPRING AND TIGHTEN 4 SET SCREWS.
- 5) LIFT TOWER ASSEMBLY ONTO BASE, & TIGHTEN 2 SET SCREWS.
- 6) CONNECT VACUUM BREAKER, UPPER HOSE ASSEMBLY & NOZZLE.
- 7) CONNECT AND PRESSURE TEST WATER SUPPLY.

ROMORT WATER TOWER
NOT TO SCALE